

gabb®

GABB WATCH 3/3e USER GUIDE



Gabb® Watch 3/3e

Table of Contents

| | |
|--|----|
| Copyrights | 1 |
| Disclaimer | 1 |
| About Your Watch | 3 |
| Getting Started | 5 |
| 1. Charging the Gabb Watch 3/3e Wirelessly | 5 |
| 2. Turning Your Watch On/Of | 7 |
| Setting Up Your Watch | 8 |
| 1. Download MyGabb App | 8 |
| 2. Set up Watch to MyGabb App | 9 |
| 3. Create Child Gabb ID | 10 |
| Using Your Watch | 11 |
| Basic Navigation | 11 |
| The Watch Face | 12 |
| Adjusting the Volume | 13 |
| Making a Call | 14 |
| Receiving a Call | 15 |
| Sending a Message | 16 |
| Receiving a Message | 19 |
| Checking Call History | 20 |
| Turning On/Off Wi-Fi | 21 |
| Turning On/Off Bluetooth | 22 |
| Fun with Our Apps | 23 |
| Alarms | 24 |
| Stopwatch | 24 |
| Timer | 25 |
| Settings | 27 |
| Volume | 28 |
| Ringtones | 28 |
| Theme | 29 |

| | |
|------------------|----|
| Display | 29 |
| Wi-Fi | 32 |
| Bluetooth | 32 |
| General | 33 |
| Focus Mode | 36 |
| Volume Control | 37 |
| Troubleshooting | 38 |
| Support and More | 40 |
| Specifications | 41 |

Copyrights

Copyright © 2025 Gabb Wireless Inc. | All rights reserved.

Gabb and the Gabb logos are trademarks of Gabb Wireless Inc.

No part of this publication may be duplicated, reproduced, shared, or used in any form, regardless written or electronically, without the prior written consent of Gabb Wireless Inc.

Gabb Wireless Inc. reserves the rights to make changes without prior notices.

Disclaimer

Information about your wireless device and third-party services.

Gabb Wireless is the mobile carrier associated with this wireless device, but many services and features offered through this device are provided by or in conjunction with third parties. Gabb Wireless is not responsible for your use of this device or any non-Gabb Wireless applications, products and services, including any personal information you choose to use, submit or share with others. Specific third-party terms and conditions, terms of use and privacy policies apply. Please review carefully all applicable terms, conditions and policies prior to using this wireless device and any associated application, product or service.



WARNING PARENTS:

This watch is not a toy. Please do not attempt to remove the battery or tamper with the seal of the battery. Manufacturer warranties may be voided or not apply due to misuse, tampering, modifications, or improper maintenance.

Please be aware that battery overheating, especially with lithium-ion batteries, can be dangerous and lead to potential fire hazards. Overheating can occur if batteries are damaged, overcharged, overused, or exposed to extreme temperatures. If battery overheats, smokes or gives off an odor, move it to safe, non-combustible surface, evacuate and call emergency services. **Keep batteries away from children.**

About Your Watch

- Front & Back



NOTE: Devices and software are constantly evolving. The screen images and icons you see here are for reference only.

- **Back**



- **Top**



- **Bottom**



Getting Started

1. Charging the Gabb Watch 3/3e Wirelessly

Your watch is charged wirelessly, without inserting the cable into the device.

- ① You should use a 5V/1A or 5V/1000mA charging block with your magnetic wireless charger.
- ② Place your watch on the wireless charging cable.
Align the back of your watch with the top side of the wireless charger.
- ③ Check the charging icon on your watch to verify that your watch is charging.



- ④ You should see the fully charged status on the screen of your watch when it is 100% charged.




NOTE:


- Only use the supplied wireless charging cable for optimal charging performance.
- To avoid interference, do NOT place any object between the watch and the wireless charging cable.
- If you don't see the charging icon appear on your watch after you place it on the wireless charging cable, contact customer support for help.

2. Turning Your Watch On/Off

Power on: To power your watch on, press and hold the Power Button until the logo shows up and enters the Home Screen.




Power off: To power it off, press and hold the Power Button until you see "Power off?" on the screen. Tap to turn off your watch.



Setting Up Your Watch

1. Download MyGabb App

The MyGabb app is necessary to set up with the Gabb Watch 3/3e to set up Contacts, GPS tracking, and more. Make sure your smartphone has access to Wi-Fi or a reliable wireless network, then download the **MyGabb** app on your smartphone from the [App Store \(iOS\)](#) or [Google Play Store \(Android\)](#).



Open the app and log in with the same email and password you used to place your order on www.gabb.com .

2. Set up Watch to MyGabb App

Once the MyGabb app is downloaded and installed, follow the on-screen instructions in the app to complete the set up.

3. Create Child Gabb ID

A Gabb ID is your child's secure user profile that will allow their contacts, Gabb Go, and more to be backed up. It will also allow your child's watch to function properly, including the ability to use GPS.

Using Your Watch

Basic Navigation

Your watch is equipped with a touch screen.

1. Swipe left or right to switch pages:

- Watch Face
- Apps
- Call & Text
 - Contacts
 - Messages
 - Call History


2. Swipe down from the Watch Face to access the Quick Setting Panel:

- Turn on/off Wi-Fi
- Turn on/off Bluetooth
- Turn on/off the Flashlight
- Go to Wallpapers
- Go to Theme app
- Go to Settings
- Adjust the Volume

The Watch Face

The Watch Face is like the Home Screen where you start navigating the device functions.


- Swipe down once to use Quick Setting panel.
- Swipe left to access Apps, then scroll down to open Settings.
- Swipe right to access Call & Text, then scroll down to view Contacts, Messages, and Call History.



Adjusting the Volume

Swipe down from the Watch Face to enter the Quick Setting panel and then drag the


 slider to adjust the volume



or


Swipe left once from the Watch Face to enter Apps, then scroll down to access Settings.

Tap  to go to the Volume screen. Then drag the  slider to adjust the volume.



Making a Call

- ① From the Watch Face, swipe right to the Call & Text, then tap Contacts. Select the contact you want to call. To start the call, tap and swipe the  icon.
- ② To end the call, tap  icon.



NOTE: Your watch can only make and receive calls from phone numbers on the contact list. You can manage the Contacts in MyGabb App on your phone.

Receiving a Call

When the watch receives a call, it will ring and the screen will show the caller's name.

- Tap  to answer the call.
- Tap  to reject or end the call.




- To adjust the volume during the call, tap the volume  icon.



NOTE: Making and receiving calls and messages requires network connection.


Sending a Message

- ① From the Watch Face, swipe right to the Call & Text, then tap Messages. Select the contact you want to send a message.




- ② Choose what you want to send:


- Select a contact or multiple contacts to send a Single or Group Message.




- To send an Audio Message, tap .




- To send an Emoji Message, tap .



- To send a Text Message, tap .



- Scroll down to select and send a Preset Text Message.



Receiving a Message

When the watch receives a new message, a notification will appear on the screen showing the sender's name. After two seconds, it will automatically transition to the message content

Tap  to reply with a message or  to call back.



NOTE: The watch can only exchange messages with contacts whose permission is allowed. You can manage contact permissions with MyGabb App on your phone.

Checking Call History

From the Watch Face, swipe right to the Call & Text. Then tap Call History to check your missed call(s), incoming call(s) and outgoing call(s).



Turning On/Off Wi-Fi

Swipe down from the Watch Face to enter the Quick Setting panel and then tap the Wi-Fi




or

Swipe left from the Watch Face to enter Apps. Scroll down to Settings.

Tap  to go to the Wi-Fi screen. Then use the toggle switch to turn it on.

Tap to select an available Wi-Fi network. Enter password if required.



Turning On/Off Bluetooth

Swipe down from the Watch Face to enter the Quick Setting panel and then tap the Bluetooth  icon.




or

Swipe left from the Watch Face to enter Apps. Scroll down to Settings.

Tap  Bluetooth to go to the Bluetooth screen. Then use the toggle switch to turn it on.

Tap to select a device to set up with.



Fun with Our Apps

Swipe left once to check out our Apps, such as Mimic by Gabb and Gabb Go.

Note that you must be logged into a Child Gabb ID for some apps to function properly.



| | | | |
|--|---|---|--|
|  | Mimic by Gabb A game to test and improve your memory and reflexes |  | Gabb Go A pet theme game by Gabb |
|--|---|---|--|

Alarms

Tap  to use the Alarm tool.

Use the toggle switch  to turn the alarm on/off.

Tap on an alarm to edit the time, day, or alarm tone for your alarm.






Stopwatch

Tap  to use the Stopwatch tool.

Tap  to start the stopwatch.

Tap  to pause the stopwatch, and tap  to resume it.



Tap  to reset the stopwatch.



Timer



Tap  to use the Timer tool.

Tap and set the hr/min/sec for your timer and press play  to start.




When the timer is running, you may tap  to pause, and then tap  to resume the timer.

Tap  to restart.



When the timer finishes running, it will flash. Tap  to reset the timer to the original set value.




Settings

Swipe left to access Apps, then scroll down to select Settings for complete settings and customization.

- Volume
- Ringtones
- Theme
- Display
 - Brightness
 - Flashlight
 - Orientation
 - Screen Timeout
 - Wake Screen
- Wi-Fi
- Bluetooth
- System Updates
- App Updates
- About Device
 - Gabb ID


Volume

Tap  Volume to adjust the volume with the slider and turn Vibrate on/off with the toggle switch.




Ringtones

Tap  Ringtones to select ringtone or text tone for your watch.




Theme

Tap  to change the Dark/Light theme and the Button Color of your watch.




Display

- Tap  to adjust the Brightness of your watch.




- Tap  to turn on/off the Flashlight.


- Tap  Orientation to change your watch's orientation to wear on your other wrist.
Left Wrist: the standard orientation for those who wear the watch on their left wrist.
Right Wrist: the standard orientation for those who wear the watch on their right wrist.



- Tap  Screen Timeout to set the Screen Timeout of your watch. You may select 5 seconds, 10 seconds, 15 seconds, 30 seconds, 45 seconds or 60 seconds.



- Tap  Wake Screen to enable or disable Raise to Wake or Tap to Wake with the toggle switch.



Wi-Fi

Tap  to enable or disable Wi-Fi for your watch with the toggle switch.

Once enabled, select an available network. Enter password if required.






Bluetooth

Tap  to enable or disable Bluetooth for your watch with the toggle switch.

Once enabled, tap  to display available devices.


Tap on a device you want to set up with your watch.




General

- Tap  to check for software or firmware updates of your watch. Your watch supports FOTA updates.

To install updates, please ensure your watch is connected to Wi-Fi network and to the wireless charger. Make sure there is above 30% power remaining in your watch.



- Tap **About Device** to view device information, including Mobile Number, Device Owner, IMEI, ICCID, System Version, Hardware Version, Model Number, Memory, Storage, and Total Call Time.



About Device

Mobile Number
1-801-987-6543

Gabb ID
george123

IMEI
123456789012345

ICCID
12345678901234567890

System Version
B1.100

Hardware Version
GW23HW1.0


Model Number
GW23

Memory (RAM)
Available: 600MB
Used: 400MB
Total: 1GB

Storage (ROM)
Available: 6GB
Used: 2GB
Total: 8GB

Total Call Time
44h 33m 12s


- Tap  App Versions to view information about App Versions.



Focus Mode

Focus Mode can be set on your Parent App.

In Focus Mode, the user can swipe right to Call & Text to access Primary and Guardian Contacts to make a phone call or send a message.



Volume Control

Adjust the volume of the watch on the MyGabb App

Troubleshooting

1. Why is there an overheating message on my watch?

A: This may happen under the following circumstances:

- **Software updating:** When your watch's software is updating, it may require more processing load to complete the task. In this case, take off your watch and wait until the update finished.
- **Low signal strength:** When you start your watch in a place where signal strength is weak, and your watch is taking longer to connect to the network. In this case, take off your watch and take it to a place with stronger signal strength.
- **Watch in a hot area:** Using your watch in high ambient temperatures or exposing it to direct sunlight can cause its internal components to heat up more easily. In this case, take off your watch and allow it to cool down in a cooler environment.
- **Too much screen time:** Prolonged use of the watch, especially with the screen on, can lead to continuous processing that may cause the watch to overheat. In this case, take a break and let your watch rest for a while.



Let's cool down!

Take a break
from the watch,
so it doesn't get hot.

Reasons for a cool down:

Software updating
Low signal strength
Watch in hot area
Too much screen time

2. Why can't I update my watch?

A: Updating the software or firmware of your watch will fail if your watch is not connected to the charger, has less than 30% power remaining, or without Wi-Fi connection. Please try to connect your watch to the charger and Wi-Fi network. Then update it again after it is charged to have more than 30% battery.

Not connected to charger

To install updates, please place the watch on the charger.



Not enough battery

Battery is below 30%. Please charge device to continue updates.




No Wi-Fi connection

To download updates you must be connected to Wi-Fi. Please connect and try again.



3. Why can't I call my contact?

A: This may happen if you are in a place without network signal. Please move to somewhere with stronger signal strength immediately.



Support and More



From the MyGabb app, tap the hamburger menu on the top right and select **Support** to learn more.



From your computer, visit gabb.com/account to manage your account, track your usage, edit account information, pay your bill and more.



From your computer, visit gabb.com/support, or email us at support@gabb.com.

Specifications

| | |
|--|---|
| Operating system | AOSP Android 11 Go |
| Chipset | Qualcomm SDW4100 (SDM429w, 4x A53 2.0GHz) |
| Memory | ePOP (RAM: 1GB LPDDR3 + ROM: 8GB) |
| Touch display | 1.41" AMOLED, 320 x 360 2D, with Touch, Anti fingerprint |
| Cellular network & Band configuration | 4G LTE Cat 1, VoLTE - B13, B4 |
| Wi-Fi | Wi-Fi 802.11 b/g/n 2.4GHz |
| Bluetooth | 4.2 |
| Positioning | aGPS/GPS/GLONASS Wi-Fi for Geo-Fence, Location and Offload |
| Sensor | Accelerometer |
| Battery | Li-polymer 500 mAh Typ., non-removable |
| Charging | Wireless charging |
| SIM | eSIM (BULKSIM-WS-MP-TE-A) |
| Buttons | 1 x Power/Home button 1 x Back/SOS button |
| Audio | 1 x Mic 1 x Speaker |
| Accessories | Wireless charging pad (magnetic) Watch bands |
| Protection | IP68 water resistance |
| Dimensions | 40 x 46 x 14.5 mm (Main body without hinge) |
| Weight | 52g (watch with band); 35.5g (watch only) |



gabb[®]